## CARBURETED CAR STARTING INSTRUCTIONS:

## COLD ENGINE STARTING, CAR HAS BEEN SITTING OVER NIGHT, OR FOR AT LEAST HALF OF A DAY:

- 1-Push gas pedal ALL the way to the floor, then take foot OFF the gas pedal.
- 2-Turn the key to the starting/cranking position until car starts, maximum 10 seconds.
- 3-If car does not start, repeat steps 1 & 2 until car starts, maximum five times.
- \*\*\*DO NOT push gas to the floor (or pump gas) more than once between starting attempts.

## WARM ENGINE STARTING, CAR HAS BEEN RUNNING WITHIN THE LAST SEVERAL HOURS:

- 1-Push gas pedal HALF way to the floor, and hold it there.
- 2-Turn the key to the starting/cranking position until car starts, maximum 10 seconds.
- 3-If car does not start, push gas ALL the way to floor and hold it there, and repeat step 2.
- 4-If car does not start, DO NOT release gas pedal from floor, but wait for 30 seconds and repeat step 2 until car starts, maximum five times.
- \*\*\*NEVER pump the gas when trying to start warm engine.

Copyright © 2003 - 2019 Automotive Management Network